

K. Apply glue just in front of the 3-7/8" (9.8 cm) mark and slide L. Apply glue fillets to the **J.** Apply glue just behind the 1/4" (6 I. Use a hobby knife outer centerina mm) mark and slide the centering to carefully remove ring/tube joints, smooth the other ring with slit onto ring with notch onto the engine the centering rings with finger, and let dry. the front of the tube and down from their card and mount tube (with notch over engine to the mark. Let drv. hook) until the ring sits evenly at to clear slot in the 1/4" (6 mm) mark. forward ring. 2. PREPARE FINS B. Remove fins from C. Keep a scrap A. Fine sand laser cut each sheet with fin sheets piece of balsa for modeling knife. glue applicator. **D.** Stack together, sand edges and round tip corners. 3. INSTALL ENGINE MOUNT **B.** Insert engine mount so ring is 1/16" (2 mm) from end and apply glue fillet. (8.3 cm) A. Smear glue (13 mm) inside one body tube using balsa stick. 4. MARK FIN AND LAUNCH LUG LINES A. Cut out Marking Guide from DOOR page 4 and wrap it around tube 1" (25 mm) from rear. **←**w Lug Align lug arrows with engine **B.** Connect marks hook. Mark tube at all arrows. with straight lines. Draw a line around tube at Draw launch lug rear of guide. Mark launch lug line "LL" full tube length. PN 82107(7-06) © 2006 Estes-Cox Corp. All rights reserved.

1. ASSEMBLE ENGINE MOUNT

(8.9 cm

A. Mark the yellow engine

spacer tube at 3/16"

(2.5 cm)

(5 mm) from one end.

(9.8 cm

E. Measure the engine mount tube from

the same end that you inserted the

at 1/4" (6 mm), at 1" (2.5 cm), at

3-1/2" (8.9 cm) and at 3-7/8" (9.8 cm).

engine block ring and mark the tube

B. Place a ring of glue about

1" (2.5 cm) inside one end

of the engine mount tube.

C. Insert the engine block ring

engine mount tube.

F. Use a hobby knife to make

a 1/8" (3 mm) wide slit at the

3-1/2" (8.9 cm) mark only.

into the opposite end of the

ENGINE BLOCK RING

D. Use the yellow engine spacer tube to push the engine block ring into the engine

SPACER TUBE!

G. Insert the engine hook

into the slit as shown.

mount tube up to the 3/16" (5 mm) mark

and IMMEDIATELY REMOVE YELLOW


H. Hold the engine hook


secure hook.


straight and wrap two

layers of masking tape at

the 1" (2.5 cm) mark to







Page 4